

PEGASI Basketball Hoop Instructions



warning:
For your safety, please don't violently dunk or hang on the hoop.

Installation reminder
*In order to be safe and save your precious time, please read the instructions carefully before installing, counterweight, display and disassembly of the basketball stand, check all the accessories in the package, and install it after mastering the installation and details.
*This product requires at least 2 adults to install, please prepare 2 adjustable wrenches.

Use safety instructions

In order to ensure safety, the user must read the instructions carefully before installation and use, and install, use, store, move and disassemble in accordance with the instructions, so as to check the solidity of the counterweight screws of the base before use to avoid damage to the product. And any damage to the user.

1. It is recommended that 2 or more adults install it, and children are not allowed to install and climb;
2. Before use, check whether the base is leaking and whether the screws are tight. A small flow of water leakage may lead to an increase in products;
3. The product is suitable for recreation and fitness. Intense and fierce competition. It is forbidden to dunk and hang vigorously;
4. After successful installation, the base must be filled with water or sand immediately to prevent it from falling upside down. The base must be placed flat on a level and level ground before use to prevent damage to the base caused by sharp objects or increased use time.

Warning

1. It is forbidden to climb or hang on the hoop, backboard bracket and bead net.
2. It is forbidden to use products with potential safety hazards. If there are parts that need to be repaired or replaced, please contact after-sales personnel or local dealers in time.
3. Special care must be taken when moving on uneven ground, which may cause side material of the product. caveat!

4. In order to avoid damage to the base due to freezing, when the temperature is lower than 0 degrees Celsius, the water in the base must be poured out or filled with sand.
5. If the product is used outdoors for a long time, please ensure that the top of the main pole and the lifting pole are covered with plastic covers to prevent rainwater from affecting the product life.
6. Please do not wear watches, necklaces, earrings and other jewelry when in use, to prevent hanging up the basket or losing it during exercise.
7. When adjusting the height, please leave your fingers away from the moving parts.
8. It is forbidden for children to move the product or adjust the height of the product.

Parts List

Accessory model	Name	Quantity	Note
B1、B2、B3	Screw , M8 X 35MM	2	Connect backboard, hoop and backboard bracket
B4、B5、B6、B7	Screw with spring , M8 X 10MM	2	Connect backboard, hoop and backboard bracket
C1、C2	Screw , M8 X 16MM	2	Fix the backboard bracket to the backboard
D1、D2、D3	Screw , M8 X 20MM	2	Connect the base and base support rod
E1、E2、E3	Screw , M8 X 90MM	1	Connect the bottom tube and the base support rod
F1、F2、F3	Screw , M8 X 85MM	6	Connect the backboard bracket and the yop pole Connect the upper middle and lower poles
G	Base cover	2	
H	Top rod cover	1	
I	Base water injection hole cover	1	
J	Basket ring	1	
K	Backboard bracket	1	
L	Nets	1	
M	Backboard	1	
U1	Base support rod (right side)	1	
U2	Base support rod (left side)	1	
O	Wheel pin	1	
W	Top pole	1	
X	Middle pole	1	
Y	Bottom pole	1	
S	Base	1	

